

3.0

Self Help Guide For Solutions Displays

Problem	Action
<p>Nothing is working</p>	<p>Ensure the power lead is properly plugged into a socket outlet</p> <p>If unsure that socket outlet is live, plug into another appliance to confirm power outlet</p> <p>Check fuse in plug top</p> <p>Make sure power/ main switch is on. Turn upper heat control fully clockwise</p>
<p>The lights do not work</p>	<p>Check that the other switches/ control knobs are turned on</p> <p>Make sure power/ main switch is on</p>
<p>Only the lights are working</p>	<p>Check that the other switches/ control knobs are turned on</p> <p>Check that the eutectic plates are down to the correct temperature</p>

If your problem is not listed or persists please contact our service department for help.

IMPORTANT: Please ensure you have your serial number before calling. On chilled units, this is situated under the base of the unit. On heated units, this can be found under the lightbox gantry.

Counterline Limited
 Unit 12, Knowsley Business Park
 Merseyside, L34 9HZ
 United Kingdom

Fax: 0151 549 2179
Web: www.counterline.co.uk



Telephone: +44(0)151 548 2211



Email: servicelog@counterline.co.uk